	TUFF DUNTRY Z - Ride Suspension	Installation manual Front sway bar end links Part # 10950 sj121207rev.02
Part # 10950 Front sway bar end links		Important customer information:
Part # 1215B 10950NB 10950INST	DescriptionQty1/2" x 15" bolt2Hardware bag1	installation.
10950NB Hardware bag 1		 have any questions or concerns, please contact our technical department @ (801) 280-2777. Also, the OEM manual should be used as a reference guide. This vehicles reaction and handling characteristics may differ from standard cars and/or trucks. Modifications to improve and/or enhance off road performance may raise the intended center of gravity. Extreme caution must be utilized when encountering driving conditions which may cause vehicle imbalance or loss of control. DRIVE SAFELY! Avoid abrupt maneuvers: such as sudden sharp turns which could cause a roll over, resulting in serious injury or death. If you desire to return your vehicle to stock, it is the customers responsibility to save all stock hardware.

Limited lifetime warranty	Important information that needs to be read installation begins:	d before
Notice to all Tuff Country EZ-Ride Suspension	-	
customers: It is your responsibility to keep your	Before installation begins, Tuff Country	EZ-Ride
original sales receipt! If failure should occur on any	Suspension highly recommends that the	installer
Tuff Country EZ-Ride Suspension component, your	performs a test drive on the vehicle. During	the test
original sales receipt must accompany the warranted	drive, check to see if there are any uncommon	sounds
unit to receive warranty. Warranty will be void if the	or vibrations. If uncommon sounds or vibration	
customer can not provide the original sales receipt. Do	on the test drive, uncommon sounds or vibrati	
not install a body lift in conjunction with a suspension	be enhanced once the suspension system ha	
system. If a body lift is used in conjunction with any	installed. Tuff Country EZ-Ride Suspension	
Tuff Country EZ-Ride Suspension product, your Tuff	recommends notifying the customer prior to	
Country EZ-Ride Suspension WARRANTY WILL BE	tion to inform the customer of these issues	s if they
VOID. Tuff Country Inc. ("Tuff Country") suspension	exist.	
products are warranted to be free from defects in		
material and workmanship for life if purchased,	Make sure to use thread locker or lock tite on all new	
installed and maintained on a non-commercial vehicle;	and stock hardware associated with the installation of	
otherwise, for a period of twelve (12) months, from the	this suspension system.	
date of purchase and installation on a commercial vehicle, or twelve thousand (12,000) miles (which ever	Special note: Before installation begins, it	is tha
occurs first). Tuff Country does not warrant or make		
any representations concerning Tuff Country Products	customers/installers responsibility to make sure that all parts are on hand. If any parts are missing, please	
when not installed and used strictly in accordance	feel free to call one of our customer service re	
with the manufacturer's instructions for such	tatives @ (801) 280-2777.	presen
installation and operation and accordance with good		
installation and maintenance practices of the	Hardware bag 10950NB includes:	
automotive industry. This warranty does not apply to	· · · · · · · · · · · · · · · · · · ·	
the cosmetic finish of Tuff Country products nor to	Description C	Quantity
Tuff Country products which have been altered,		-
improperly installed, maintained, used or repaired, or	S10110 (.750" x .563" x 9.500" sleeve) 2	2
damaged by accident, negligence, misuse or racing.	S10113 (over size washer) 8	3
("Racing is used in its broadest sense, and, for	MO3808 (poly bushings) 8	
example, without regards to formalities in relation to	12UN (1/2" unitorque nuts) 2	2
prizes, competition, etc.) This warranty is void if the		
product is removed from the original vehicle and	Recommended tools selection:	
re-installed on that or any other vehicle. This warranty	Torque wronch	
is exclusive and is in lieu of any implied warranty of	Torque wrench Standard socket set	
merchantability, fitness for a particular purpose or other warranty of quality, whether express or implied,	Standard wrench set	
except the warranty of title. All implied warranties are	Metric socket set	
limited to the duration of this warranty. The remedies	Metric wrench set	
set forth in this warranty are exclusive. This warranty	Tape measure	
excludes all labor charges or other incidental of	Hydraulic floor jacks	
consequential damages. Any part or product returned		
for warranty claim must be returned through the		
dealer of the distributor from whom it was purchased.		
Tuff Country reserves the right to examine all parts		
returned to it for warranty claim to determine whether		
or not any such part has failed because of defect in		
material or workmanship. The obligation of Tuff		
Country under this warranty shall be limited to		
repairing, replacing or crediting, at its option, any part		
or product found to be so defective. Regardless of		
whether any part is repaired, replaced or credited		
under this warranty, shipping and/or transportation		
charges on the return of such product must be prepaid		
by the customer under this warranty.		

Front sway bar end link installation:

1. To begin installation, block the rear tires of the vehicle so that the vehicle is stable and can't roll backwards. Safely lift the front of the vehicle and support the frame with a pair of jack stands. Place a jack stand on both the driver and the passenger side.

Working on the driver side, remove the sway bar end link from the stock location. The end link and all hardware may be discarded. Repeat procedure on the passenger side.

3. Locate the new sway bar end link hardware. Working on the driver side, install the new sway bar end link hardware into the stock location on the stock sway bar and the stock lower control arm. Do not tighten at this point. Repeat procedure on the passenger side. Special note: When the new hardware is installed we want to make sure that the head of the bolt is on top of the stock sway bar and not installed to the stock lower control arm. Also, we do not want to torque the new end link until the weight of the vehicle is on the ground.

4. Carefully lower the vehicle to the ground.

5. Working on the driver side, torque the new sway bar end link hardware to **32 ft lbs.** Repeat procedure on the passenger side.

Photo #1

Congratulations, installation complete!

Special note: After the completion of the installation, Tuff Country EZ-Ride Suspension recommends taking the vehicle to an alignment shop and having a proper front end alignment performed.

Tuff Country EZ-Ride Suspension recommends that a complete re-torque is done on all bolts associated with this suspension system. It is the customers responsibility to make sure that a re-torque is performed on all hardware associated with this suspension system after the first 100 miles of installation. It is also the customers responsibility to do a complete re-torque after every 3000 miles or after every off road use. Neglect of following these steps could cause brackets to come loose and cause serious damage to the suspension system and to the vehicle.

If you have any questions or concerns, please feel free to contact Tuff Country or your local Tuff Country dealer.



Photo # 1