

**RANCH HAND**

**1-800-366-9712**

**INSTALLATION INSTRUCTIONS**

**2000-`06 CHEVY TAHOE & SUBURBAN**

**2003-`06 CHEVY AVALANCHE w/o BODY CLADDING**

**2000-`06 GMC YUKON & YUKON XL**

**PART # BBC008BLS**

*NOTE: You can keep your factory receiver hitch on the 8" drop only!*

1. If factory receiver hitch is present, remove the two bolts that hold the bumper and receiver hitch together.
2. Loosen bolts that hold the receiver hitch to the frame and let hang down. *Note: Steps 1 & 2 only apply to the 8" drop. Remove receiver hitch for the 10" drop.*
3. Remove six 18mm bolts, three per side, and slide factory bumper out.
4. Slide Ranch Hand back bumper inside frame rail. Place spare tire guide into tubing on back bumper.
5. Raise the receiver hitch and place two ½" x 1 ¾" bolts through receiver hitch and back bumper. *8" drop only!*
6. Tighten receiver hitch to frame and then receiver hitch to back bumper.
7. Torque ½" bolts to 110 ft. lbs. dry.
8. **MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!**

---

**WARNING**

---

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 10/14/08