



Truck and Jeep Accessories



GO EVERYWHERE

Like
Us



Share
Us



Watch
Us



Follow
Us



Truck and Jeep Accessories

INSTALLATION INSTRUCTIONS



2015-18 Jeep Renegade ROCK SLIDERS KJ50012BK

www.DaystarWeb.com
Tech Support Contact Info
Tech@DaystarWeb.com

Phone: 623.907.0081
Fax 623.907.0088
841 S 71st Ave
Phoenix AZ 85043

Instruction Sheet P21840
©2016 Daystar Products

Revision 3
Revision: Date 07-06-16
Revised by: PA

Introduction

Daystar Products is your number one source for Made-in-the-USA quality vehicle accessories, now backed with our exclusive GO EVERYWHERE® Lifetime Limited Warranty (see terms at DaystarWeb.com).

To ensure your safety and proper installation of this product, read all instructions and product safety information BEFORE installing your **Daystar** product. If you have technical questions after reading these instructions we are here to help. Contact us at 800-595-7659.

Product Safety Information

Throughout these instructions, important safety information is preceded by one of the three signal words indicating the relative risk of injury. The signal words are as follows:

!WARNING A hazardous situation which, if not avoided, could result in serious injury or death. You can be seriously injured or killed if you don't follow instructions.

!CAUTION A hazardous situation which, if not avoided, could result in minor or moderate injury. You can be moderately injured and also may suffer property damage if you don't follow instructions.

!NOTICE Careful attention is required to this instruction or operation but this does not generally relate to personal injury. Damage to your product or other property may result if you don't follow instructions.

!Warning: Read and understand all vehicle manufacturer and **Daystar** warnings, instructions, and limited warranties. Also, be aware that many states/countries have laws governing on-road vehicle modifications. You are responsible for ensuring the safety and legality of your vehicle. A summary of current state vehicle laws is available at www.sema.org.

Daystar® Go Everywhere Lifetime Limited Warranty

Your Daystar Comfort Ride™ or Budget Boost™ leveling kit is covered by the following **Go Everywhere Lifetime Limited Warranty** provided exclusively by Daystar Products International, Inc., 841 South 71st Ave., Phoenix, AZ 85043 ("Daystar").

What is Covered? Real Life Use, Off Road & On: Subject to the terms, exclusions and limitations herein, Daystar warrants to the initial retail purchaser that your Comfort Ride™ or Budget Boost™ leveling kit shall be free of defects in material and workmanship for so long as it is properly installed on a single vehicle owned by the initial retail Daystar purchaser.

What is Not Covered? Your Vehicle & Parts That Are Not Daystar's Go Everywhere: Your Daystar Limited Warranty does not cover: (a) damage to your vehicle, vehicle systems (ex. electronic stability control), other products, components or property not manufactured by Daystar to our exclusive Go Everywhere standards, (b) customer choice of vehicle configuration/tire and wheel combinations contrary to Daystar recommendations, warnings or applicable laws, (c) Acts of God, weather, corrosion, accidents, theft, vandalism, negligent misuse or intentional damage, other exclusions under your OEM Limited Warranty.

Remedy Limited to Repair/Replacement. Get back on your favorite trail fast: The exclusive remedy provided hereunder shall, upon Daystar's inspection and option, be either repair or replacement of the Comfort Ride™ or Budget Boost™ leveling kit or parts covered under this Limited Warranty. Call us at 623-907-0081 and we will get you back wheelin'. All labor, removal, shipping and installation costs are the customer's responsibility.

Other Exclusions – Limitation of Damages - Your Rights Under State Law. (Stuff Lawyers Say): At Daystar, we aren't big fans of lawyers, even ours. Still, he says our Limited Warranty has to include this stuff. In consideration of the purchase price paid, neither Daystar nor any independent Daystar distributor or repair person are responsible for any time loss, loss of vehicle use, rental costs, transportation, labor or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. No Daystar employee or independent distributor is authorized to make any statement or representation altering the terms of Daystar's Go Everywhere Lifetime Limited Warranty. Your exclusive remedy hereunder for covered parts is repair/replacement as described above. This Limited Warranty gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability, fitness for a particular purpose or other implied warranty are limited to a period of four (4) years from date of initial retail purchase. Daystar reserves the rights to: (a) require invoice or other proof of purchase; (b) make future revisions to these products and Limited Warranty without prior notice or obligation to upgrade your Daystar product.

©2016 Daystar Products International, Inc. All rights reserved.

DAYSTAR
Truck and Jeep Accessories

MADE IN THE USA
10 YEAR WARRANTY

CAM CAN®
LIQUID & GEAR STORAGE

SAFE SECURE LIQUID & GEAR STORAGE

MOUNTS JUST ABOUT ANYWHERE

ROLL BAR SPARE TIRE FLAT SURFACE

Each Cam Can® holds 2 gallons

DRINKING WATER TRAIL BOX STORAGE FUEL & LIQUIDS

MOUNTS JUST ABOUT ANYWHERE!

Garage Trailer Pickup Bed Roll Bars

| COLOR | | | | USAGE |
|-------|----|----|----|-----------|
| RB | | | | WATER |
| BK | TN | GE | GN | LIQUIDS |
| BK | TN | GE | OR | TRAIL BOX |

www.CAMCANS.com

!Warning: Always work with appropriate personal safety gear including safety glasses, gloves, and hearing protection when using air-powered tools.

INSTRUCTIONS

Supplied Components:

Rock Slider - Driver (1)
Rock Slider - Passenger (1)

Hardware Bag Kit BU21839 Contents:

1/4-20 x 1 Bolt, Grade 8 Y/Z (10)
1/4-20 Stover Nut (10)
1/4 SAE Flat Washer, Grade 8 Y/Z (20)
Plastic Clips (6)
3/16" High Tensil Steel Rivets (60)

The installation of this product requires a 3/16" capable air powered rivet gun and a small 3/8" drill with 3/16" and 1/4" drill bits. It also requires minor trimming using a cutoff wheel or sheetmetal sheers. It is recommended the installation is performed by a professional.

READ ALL INSTRUCTIONS BEFORE STARTING.

Important! All upper holes in the door jamb are 3/16" (rivet holes) and the lower holes through the pinchweld are 1/4" (bolt holes).

Identify driver and passenger rockers and orientation. They are labeled.

Install 1 side at a time.

REMOVING PLASTIC ROCKER COVERS

1. Raise vehicle and remove both driver side wheels.
2. Remove screw securing forward end of plastic rocker trim to inner fender liner and body.



3. Remove the screw securing the rear end of the plastic rocker trim to the inner fender liner and body.



4. Located on the bottom of Renegade's plastic rocker trim, you will find 6 plastic fasteners securing it to brackets extending from the pinch seam. Use a flathead screw driver to lower the fastener locking pins remove the fasteners from the plastic rocker trim.



9. Carefully lower and remove the rock slider.
10. Recreate the marks on the outward facing lip of the pinch seam and a 1/4" hole at each location.
11. Return the rock slider to position and loosely secure it to the pinch seam. This will keep it from moving when drilling rivet holes.
12. Drill 3/16" rivet holes using the rocker as a guide.
Note: Holes closest to the front door and rear door require a 90 degree drill.



13. Use 3/16" pop rivets to secure rocker to Renegade. Rocker must be tight against sheetmetal before riveting. You may need to clamp it to hold it tight before riveting.
14. Secure the lower mounting edge to the pinch weld by tightening the bolts and nuts loosely installed in step 11.
15. Reinstall wheels.
16. Repeat instructions for other side.



Note: Use a towel, rag or 2x4 between jack and rocker to avoid scratching the powdercoat.

6. Push slider all the way forward of the vehicle, then put slight pressure on slider with jack to hold in place. Note: The circular cutout of the rocker will match the circle in the door opening.
7. Tuck the front and rear fender liners between the rock slider and the pinch seam.
8. Using the rock slider as a template, mark where you will need to drill 5 holes on the *inner* lip of the pinch seam.



5. Using a 5mm allen wrench, remove the bolt next to the "NO STEP" warning label that secures the plastic rocker trim to body of your Renegade.



6. Pull the plastic rocker trim down and away to separate it from the plastic mounting tabs
7. Pull the fender trim away from the body to access the final tab securing the plastic rocker trim to the body. It is hidden behind the plastic fender trim.
8. Find the plastic tongue connecting the rocker trim to the fender trim. Wriggle it free of the slot to completely remove the rocker trim.



(The kit includes replacement tabs. To insert, slide the square side into the mounting slots. Push the barbed end into the respective hole until it clicks into place.)

INSTALLATION

1. Using a razor knife, remove high spots of glue from the backside of the pinchweld and the underside of the rocker, creating a flat surface for the rocker to mount. Proper installation requires a flush surface.



2. Cut off the 6 rocker trim mounts from the pinch seam. Cut them flush with the bottom of the pinch weld. These must be trimmed or the rocker will not fit into place.



Note: When the glue is removed and the front and rear tabs that held the plastic panel are trimmed off, the rocker will fit snugly against the bottom of floor behind the pinchweld, the bottom of the rocker and the door jamb; there will be no doubt that it is in

place. Note: Do not drill any holes until it is in place!

3. Trim 1" off the bottom of the front plastic inner fenderwell. Cut to just past the rectangular pinch seam dimple.



Note: This allows the lower corner of the front plastic inner fenderwell and the rear fenderwell to tuck into the rock slider.

4. Open both driver side doors.
5. Using a floorjack, carefully raise the rock slider until it's flush against the body. Make sure the pinch seam sits inside the rock slider and that the circular cutout on the upper edge is positioned around the round dimple on the body.