



LIFT AND LEVEL KITS

Toll free: 888-660-5892

email: info@truxxx.com

SAFETY WARNING!

Always use the correct tools, and wear safety goggles. We **STRONGLY** recommend installation by a licensed mechanic on a properly secured locking lift.

Truxxx Manufacturing LLC
810 E 19th Street, Tucson AZ 85719

TIRE FITMENT ADVICE

The best way to ensure proper tire fitment is to install the kit before purchasing your wheels and tires. Always test fit tires and wheels before purchasing.

VEHICLE RIDE WARNING!

Trucks with lift or level kits installed have a higher center of gravity. Aggressive and sudden direction changes may cause a tip over.

104005 Ford F150 Rear Lowering Shackle

This kit contains:

2 - Rear Lowering Shackles

Instructions

Warranty Card

Stickers



Installation Tips

Always use caution handling ABS or wheel sensor wiring. Avoid tension of any kind on wiring harness as this may cause damage or failure.

1. Trucks are often not level side to side from the factory. Please measure before installation.
2. Re-torque all hardware to manufactures specifications
3. When aligning, to get the best tire wear use our supplied specifications. OEM specifications are for trucks with stock wheels and tires. Larger tires will wear differently.
4. All instructions are written with vehicle on a 2-post lift with tires removed.

Step 1

Support rear differential with jacks.

Step 2

Starting on one side of the truck, place a jack under the leaf spring near the end of the spring. Loosen the upper OEM shackle bolt. Remove the lower bolt. The end of the leaf spring may need to be raised above the frame to allow for removal of the upper bolt.

Step 3

Install the Truxxx shackle in reverse of dis-assembly, selecting either the 1" or 2" drop mounting positions. Repeat installation on opposite side.