## **INSTALLATION INSTRUCTIONS**

PART#4415(B-C-PS)

## 07-13 TOYOTA TUNDRA DOUBLE CAB

Parts list:

QTY (1) Side bar set

(1) Front brackets set

(1) Rear brackets set

(1) 37182 Hardware kit includes:

(4) 1/2 x 2" hex head bolt

(4) 1/2" flat washer

(4) 1/2" lock washer

(8) 3/8" Flat washer

(8) 3/8" Lock washer

(8) M8 x 25mm Hex head bolt





Driver side rear bracket

Required tools

13 mm Socket/wrench

12 mm Socket/wrench

Ratchet Extension


3/4" Socket/wrench

Instructions:


Ratchet Approx. Installation time: 35 min.

- 1. Read carefully and understand instructions before beginning installation. If any part is missed, please stop installation and call to your distributor to get the missing pieces.
- 2. Locate existing threaded holes inside the rocker panel at front of vehicle. Remove existing bolts if necessary. Picture 1.
- 3. Place front bracket and secure it using (2) M8 x 25mm hex head bolt, (2) 3/8" flat washer, (2) 3/8" lock washer. Do not tighten yet. Picture 2.

**PICTURE 1** 



PICTURE 2



Clean and care instructions:

Design:

Quality:

Keep your product clean. Do not use abrasive cleaners or polish. We recommend only non-abrasive automotive wax such as pure carnauba.

Checked 04/01/09

G:\Usuarios\Diseño\Instructivos PDF\37`s\37002.Pdf


1 de 2 FODI7.003.E

## **INSTALLATION INSTRUCTIONS**

**PART#4415(B-C-PS)** 

4. To install rear bracket, locate threaded holes inside the vehicle's rocker panel, then remove bolts if necessary. Place rear bracket, and secure it using: (2) M8 x 25mm hex head bolts and (2) 3/8" lock washers and (2) 3/8" flat washers. Picture 3. Do not tighten yet.

## PICTURE 3



- 5. Mount side bar on brackets and secure it using: (1) 1/2 x 2" hex head bolt and 1/2" flat and lock washers by each bracket. Leave loose.
- 6. Adjust and align the side bar, then tighten all bolts.
- 7. Repeat all steps for the other side of vehicle.
- 8. Remember to check periodically your product. Maybe it will need a bolt re.tighten.
- 9. Fill out warranty card and place it on your vehicle's glove box.

Clean and care instructions:

Design:

Quality:

Keep your product clean. Do not use abrasive cleaners or polish. We recommend only non-abrasive automotive wax such as pure carnauba.

2 de 2

Checked 04/01/09

G:\Usuarios\Diseño\Instructivos PDF\37`s\37188oe.pdf

FODI7.003.E