



Description: Tail light
Part Number: 321002-321124
Application: BMW 3 SERIES E36 92-98 2 DR



Tools needed: 8mm Socket

Step 1: Turn the locking pin to remove the tail light cover.



Step 2: Locate the wire harness.



Step 3: Locate the four 8mm screws and remove them



Step 4: Unplug the wire harness from the tail light.



Step 5: Remove the tail light from the car.



Step 6: Put the new Anzo light in and screw on the 8mm nuts to secure the tail



Step 7: Plug the wire harness into the new Anzo lights.



Step 8: Now check all functions to make sure they are in working order before driving.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.