



Installation Manual:

Part Number: 211058, 211138
& 211060

Ford F-150 (04-08)

Tail Light (LED Style): Black, Red
Clear & Chrome

Completely read all the instructions before installation
Improper installation will void warranty!

Step 1



Tools needed:
8mm Socket

Step 2



Remove the two 8mm screws
located on the side of the tail
light housing

Step 3



Remove the OEM tail light by
removing the light sockets from the
tail light housing

Step 4



Remove the Anzo tail light out of
its box

Step 5



Install the Anzo tail light by
reversing steps 2 to 3

Step 6



Test all functions before
operating the vehicle

information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

