



5150 Eucalyptus Avenue Unit A
 Chino, Ca. 91710
 888.360.3696
 www.anzousa.com



Installation Manual:

Part Number: 121172
 INFINITI G35 03-04 4DR CRYSTAL
 HEADLIGHT BLACK

Tools Needed:

10mm socket Wrench

Completely read all the instructions before installation
 Improper installation will void warranty!

Step 1



To install new headlights, start by opening the hood.

Step 2



Remove (6) push pins located on top of the grill.

Step 3



Gently pull the fender wall cover towards you. Remove (1) 10mm bolt.

Step 4



Remove (1) 10mm bolt located towards the inner part of the side bumper.

Step 5



Gently pull the side bumper towards you and place a rag to prevent damage on vehicle.

Step 6



Remove the bumper by pulling towards you.

Step 7



Remove (1) 10mm bolt located on top of the headlight.

Step 8



Remove(3) additional bolts from the headlight located on the bottom.

Step 9



Remove the OE harness from the headlight.

Step 10



Remove headlights from vehicle.

Step 11



Install new headlights by reversing steps 10-2.

Step 12



Test all functions before operating the vehicle.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.

1