



2650-1866-77

1955-56 CHEVY CAR CLOCK INSERT

Model 7058

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. The tabs on the back of the circular section of the stock bezel will need to be removed or filed down.
3. Place & hold the front insert into the stock bezel.
4. Place the rear insert on the back side of the stock bezel & attach with the 1 1/2" x 10-32 screws provided with this product.

866-248-6356

www.autometer.com

2650-1866-77 12/7/15



2650-1866-77

1955-56 CHEVY CAR CLOCK INSERT

Model 7058

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. The tabs on the back of the circular section of the stock bezel will need to be removed or filed down.
3. Place & hold the front insert into the stock bezel.
4. Place the rear insert on the back side of the stock bezel & attach with the 1 1/2" x 10-32 screws provided with this product.

866-248-6356

www.autometer.com

2650-1866-77 12/7/15



2650-1866-77

1955-56 CHEVY CAR CLOCK INSERT

Model 7058

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. The tabs on the back of the circular section of the stock bezel will need to be removed or filed down.
3. Place & hold the front insert into the stock bezel.
4. Place the rear insert on the back side of the stock bezel & attach with the 1 1/2" x 10-32 screws provided with this product.

866-248-6356

www.autometer.com

2650-1866-77 12/7/15