

BODY MOUNT INSTRUCTIONS 97-02 JEEP TJ WRANGLER

- 1) MAKE SURE ENGINE AND RADIATOR ARE BOTH COOL.
- 2) SPRAY EXISTING BODY MOUNT BOLTS WITH LUBRICANT/RUST REMOVER
- 3) DISCONNECT OVERFLOW HOSE FROM THE RADIATOR AND REMOVE OVERFLOW TANK.
- 4) REMOVE FOUR (4) BOLTS FROM THE FAN SHROUD AND MOVE SHROUD TOWARDS THE ENGINE.
- 5) LOOSEN ONE (1) SIDE OF EXISTING BODY MOUNTS THEN REMOVE BOLTS FROM THE OPPOSITE SIDE.
- 6) WHEN JACKING THE BODY, USE A LONG 2X4 OR 4X4 FOR SUPPORT. NEVER PUT JACK DIRECTLY ON BODY PANELS.
- 7) SLOWLY JACK BODY UP, CHECKING THE FAN AND 4-WHEEL DRIVE SHIFT LINKAGE FOR SUFFICIENT CLEARANCE.
- 8) REMOVE THE OLD MOUNTS AND REPLACE WITH THE NEW MOUNTS. REINSTALL BOLTS BUT DO NOT TIGHTEN.
- 9) REPEAT STEP 8 FOR THE OPPOSITE SIDE, WHILE CONTINUING TO CHECK FOR CLEARANCE.
- 10) DO NOT TIGHTEN BOLTS UNTIL ALL 12 BODY MOUNTS ARE REPLACED.

NOTE: AFTER 2 WEEKS OF USE RETORQUE ALL BOLTS TO FACTORY SPECIFICATIONS.

POSITIONS A, E AND F : M02288
10 BUSHINGS TOTAL M02429
S10125

POSITIONS B, C, AND D : M02348
12 BUSHINGS TOTAL M02350
S10125

