

**BRACKET RUNNING  
BOARD 5**

**390555 / 6843405**


**INSTALLATION INSTRUCTIONS**

**NISSAN ROGUE (SENSE - ADVANCE - EXCLUSIVE )**

**2008 - 2013**



| Parts List                                    |          |                |   |             |
|---|----------|----------------|---|-------------|
| Item  | Qty.     | Code           | Description                                 | Max. Torque |
| <b>1 Kit BRK-390555 Hardware brackets kit</b> |          |                |   |             |
| 1   | 1 Set    | 390550AA       | Front bracket.                              | -           |
| 2   | 1 Set    | 390550BA       | Rear bracket.                               | -           |
| 3   | 1 Set    | 390554AA       | Auxiliary front bracket.                    | -           |
| 4   | 2 Piece  | 390552CA       | Auxiliary rear bracket.                     | -           |
| 5   | 4 Piece  | 370200AA       | 3/8 x 1 1/2" Bolt plate.                    | 30 Lb.ft    |
| 6   | 2 Piece  | 12104138-T13AA | 3/8 x 1 1/2" Bolt plate.                    | 20 Lb.ft    |
| 7   | 2 Piece  | 390550CA       | 5/16" Bolt plate.                           | 20 Lb.ft    |
| <b>1 Kit KTE-390555 Hardware bolts kit</b>    |          |                |   |             |
| 8   | 8 Piece  | -              | 5/16" Square head bolt. Zinc black          | 11 Lb.ft    |
| 9   | 10 Piece | -              | 5/16" Flat washer. Zinc black               | -           |
| 10  | 8 Piece  | -              | 5/16" Lock washer. Zinc black               | -           |
| 11  | 2 Piece  | -              | 5/16" Hex nut. Zinc black                   | 20 Lb.ft    |
| 12  | 2 Piece  | -              | M6x20mm Hex. flange head bolt. Zinc black   | 20 Lb.ft    |
| 13  | 2 Piece  | -              | 3/8 x 1" Hex. Head bolt. Zinc plate         | 30 Lb.ft    |
| 14  | 8 Piece  | -              | 3/8" Flat washer. Zinc plate                | -           |
| 15  | 8 Piece  | -              | 3/8" Lock washer. Zinc plate                | -           |
| 16  | 8 Piece  | -              | 3/8" Hex nut. Zinc plate                    | 30 Lb.ft    |
| 17  | 2 Piece  | -              | 3/8 x 1 1/4" Carriage head bolt. Zinc black | 30 Lb.ft    |
| 18  | 2 Piece  | -              | 3/8" Flat washer. Zinc black                | -           |
| 19  | 2 Piece  | -              | 3/8" Lock washer. Zinc black                | -           |
| 20  | 2 Piece  | -              | 3/8" Hex nut. Zinc black                    | 30 Lb.ft    |
| 21  | 1 Piece  | -              | 3/8" Bolt guide                             | -           |

| Required Tools (Not included) |                       |
|-------------------------------|-----------------------|
| Qty.                          | Description           |
| 1                             | 9/16" Socket & Wrench |
| 1                             | 13mm Socket & Wrench  |
| 1                             | 1/2" Socket & Wrench  |
| 1                             | Flat screw driver     |
| 1                             | Ratchet               |
| 1                             | Extension             |




**Instructions**

- 1.- Before beginning the installation, please read all directions carefully and verify that all necessary hardware is accounted for. If any parts are missing, stop the installation and contact your distributor immediately.
- 2.- To maintain and care this product keep it clean and do not use abrasive cleaners or polish waxes. We recommend to use only non-abrasive automotive wax such as pure carnauba to avoid scratches and rust.
- 3.- The approximate installation time is 45 min.
- 4.- Locate the square hole in the front of the body and insert 3/8 x 1 1/2" bolt plate ( See image 6 of table Product image ), according to **PICTURE 1 y 2**.



**PICTURE 3.**




In this part, under the vehicle install the driver side front bracket.

In this part, under the vehicle install the driver side rear bracket.


5.- Place the driver side front bracket and secure with: 3/8" flat and lock washer, 3/8" hex nut. Leave loose. **SEE ILLUSTRATION 1.**

6.- Locate and remove the screw shown in **PICTURE 4**, Place the upper bracket driver side front. Replace the screw removed by: M6x20mm Hex. flange head bolt and attach the front auxiliary bracket. **SEE PICTURE 4.**

**PICTURE 4.**



**ILLUSTRATION 1.**




7.- Locate the holes in the rear of the chassis as shown in the **PICTURE 5**. Insert 3/8" bolt guide in 3/8 x 1 1/2" bolt plate, tuck the larger hole and pull the small hole. **SEE ILLUSTRATION 2, PICTURE 5.**

**PICTURE 5.**



**ILLUSTRATION 2.**



8.- In the larger hole also insert 3/8 x 1 1/2" bolt plate, but without using 3/8" bolt guide, Make sure they are as **PICTURE 6.**

**PICTURE 6.**




9.- Place the driver side rear bracket and secure with: 3/8" flat and lock washer, 3/8" hex nut. **SEE ILLUSTRATION 3.** Leave loose.

10.- Locate the hole shown in the **PICTURE 7** and insert 3/8 x 1" hex head bolt. Place the rear auxiliary bracket and attach with: 3/8" flat and lock washer, 3/8" hex nut. At the other end attach to the rear bracket: 3/8" carriage head bolt, 3/8" flat and lock washer, 3/8" hex nut. Leave loose. **SEE ILLUSTRATION 4.**


**PICTURE 7.**



**ILLUSTRATION 3.**



**ILLUSTRATION 4.**



11.- Make any final adjustments to the alignment of the bracket and tighten all bolts.

**Repeat the above steps to install the passenger side.**

12.- Periodically check your product because it may need a re-tighten of bolts.